



Printed Nest

Birdfeeder 4.0 MANUAL


Step 1 : Assemble your Birdfeeder




Put antlers together with Birdfeeder. Using few drops of glue for fixing is recommended.



While pushing antlers in the hole, don't move them up and down!





While pushing antlers in the hole, little moves to the left and right are fine.



If you have this position, you are done.


Step 2 : Stick on window



Remove covers from all four legs.



Before sticking Birdfeeder, window glass must be clean and dry!



Now you can stick Birdfeeder on the window and put bird fodder inside.



Beware of Birdfeeder conditions!




+ 30 °C
+ 86 °F



- 20 °C
- 4 °F


Step 3 : Installing safety system



Safety system prevents Birdfeeder falling down out of the window.



Remove cover from safety button.



Stick safety button on window frame from interior. Safety fibre has to be tighten.



Now your Birdfeeder instalation is complete.

Step 4 : Join our community

- 1 Visit our web page ***www.printednest.com***
- 2 In top right corner, click on ***sign in***.
- 3 Fill in registration, or join by Facebook or Twitter account.
- 4 Fill in your particular info and place pin of your birdfeeder location in the map below.
By clicking on ***Upload image***, upload image of your birdfeeder and click on ***Save changes***.
- 5 You are now part of Printednest community. You can see all birdfeeders in the world map on ***http://www.printednest.com/community***
- 6 Thank you for buying our product and supporting bird community. If you need help or you have any suggestions, contact us on ***info@printednest.com***

Printed Nest

3D printed product/Urban development
www.printednest.com